




➤ Using Bluetooth APP

For iOS system:

- ① Open the APP store




- ② Click to search the APP - [Frog Otto](#)







③ Tap to open the [Frog Otto](#)




④ Done uploading the code, connect the Bluetooth module, the LED on the Bluetooth module will flash. To open Bluetooth, click the "Connect" on the APP upper left corner, searching and connecting Bluetooth.








- ① Click to connect the Bluetooth. HMSoft connected, Bluetooth LED will turn on normally.















The Bluetooth APP interface is shown below:








Button	Function	
CONNECT	pair and connect HM-10 Bluetooth module	
Bluetooth	enter Bluetooth control interface	
DISCONNECT	disconnect the Bluetooth	
	Control character	Function
	Press: F Release: S	Press the button, robot goes front; release to stop
	Press: B Release: S	Press the button, robot goes back; release to stop
	Press: L Release: S	Press the button, robot turns left; release to stop



	Press: R Release: S	Press the button, robot turns right; release to stop
	Press: 1 Release: S	Press to wander left; release to stop
	Press: 2 Release: S	Press to wander right; release to stop
	Press: 3 Release: S	Press to kick right; release to stop
	Press: 4 Release: S	Press to kick left; release to stop
	Press: 6 Release: S	Tap to tilt right, then slowly turn back
	Press: 7 Release: S	Tap for SHADOWSTEP
	Press: 8 Release: S	Press to rub; release to stop
	Press: G Release: S	Press to swing left and right
	Press: 9 Release: S	Press to jump; release to stop



	Press: H Release: S	Press to start swimming motion; release to stop
	Press: J Release: S	Tap to slowly pick up feet and put it down
	Press: P Release: S	Tap to dance
	Tap once to send: U Tap again to send: S	Start ultrasonic avoiding function
	/	Tap once to start the mobile gesture control; tap again to close